




Helios DC Timer




No "Page" LED on showing Battery Voltage: 12V



Click down for less than 3 seconds then release to change the "page".

Click down for more than 3 seconds then release to disable/enable the motor.




Rotate the knob to the left to change the settings of the current page lower.



Rotate the knob to the right to change the settings of the current page higher.

There are 3 LEDs that represent 3 pages. Click down the "Rotary Switch" and release (*less than 3 seconds*) to change between them:



Above 99f = 0F (setting is off)
If temperature is above limit set motor = OFF



How many times the motor turns on per minute.
Values can be set between 0-10



How many seconds the motor stays on every cycle.
Values can be set between 0-6 seconds